



THREE RELAY CONTROL WIRING TERMINALS. CONNECT TO COM & NC. DO NOT USE SOLID CORE WIRE. RELAYS OPERATE IN "FAIL SAFE" CONFIGURATON.

INSTALLER SUPPLIED LINE VOLTAGE (90-240 VAC, 50-60 HZ)

DAISY-CHAIN POWER & GND WIRES RUNNING TO ADDITIONAL ART TRANSMITTERS. NOTE THAT ONE SIGNAL WIRE MUST BE PULLED FOR EACH ADDITIONAL ART TRANSMITTER ADDED.

CRITICAL ENVIRONMENT TECHNOLOGIES CANADA INC. www.critical-environment.com

QCC TO REMOTE ART TRANSMITTER WITH RSH-24V USING STROBE OUTPUT DRIVE WIRING CONNECTION DRAWING REV-A Feb 15, 2017